

NOTES:

- 1) METAL FOIL TAPE MUST COVER THE ENTIRE LENGTH OF SARNAFIL OR SIKAPLAN MEMBRANE AT TIE-IN 2) METAL FOIL TAPE MUST BE PLACED ALONG THE LEADING EDGE OF THE NON COMPATIBLE MATERIAL
- AND 1' UP ALL LAP EDGES OF THE NON COMPATIBLE MATERIAL TO MITIGATE BLEEDING OF
- NON-COMPATIBLE MATERIALS ONTO SIKA SARNAFIL MEMBRANES
- 3) ANY CONTAMINATION OF THE SIKA SARNAFIL MEMBRANE MUST BE CORRECTED PRIOR TO WARRANTY ISSUE.
- 4) SEALANT IS A MAINTENANCE ITEM AND IS NOT COVERED UNDER THE WARRANTY.

