

NOTES:

ATA SHEETS, AND MATERIAL SAFETY DATA SHEETS. ALL SALE OF

- 1) NEW OR EXISTING WOOD NAILERS SHALL BE ATTACHED ACCORDING TO THE DESIGNER OF RECORD., THE NATIONAL BUILDING CODE OF CANADA, LOCAL CODE, OR INSURANCE REQUIREMENTS, WHICHEVER IS MORE STRINGENT. NAILER HEIGHT TO MATCH TOP SURFACE TO WHICH MEMBRANE IS TO BE APPLIED.
- 2) BRING BAREBACK MEMBRANE OVER ROOF EDGE AND DOWN OUTSIDE FACE OF WALL, COVERING WOOD NAILER(S) COMPLETELY.
- 3) BRING FELTBACK MEMBRANE TO ROOF EDGE ONLY. SEE CAN 1-1-FB
- 4) FOR PERIMETER EDGE AIR SEAL TERMINATION SEE CAN 1



SIKA'S TERMS AND CONDITIONS OF SALE AVAILABLE AT WWW.CAN.SIKA.COM