



NOTES:

- 1) PENETRATION MUST BE CLEAN AND FREE OF CONTAMINATION OR LOOSE PARTICLES
- 2) PENETRATION MUST BE PRIMED WITH THE APPROPRIATE PRIMER BEFORE APPLYING SIKALASTIC MEMBRANE
- 3) GAPS AT THE BASE OF THE BEAM FLASHING MUST BE FILLED IN PRIOR TO MEMBRANE FLASHING
- 4) REFER TO LAM CAN 1-0 FOR AN ANGLE TRANSITIONAL WITH CRACKS.
- 5) PAINTERS TAPE OR METAL FOIL TAPE SHALL BE USED AT THE TOP OF THE PENETRATION FLASHING TO ENSURE A UNIFORM FINISH AND WILL BE REMOVED IMMEDIATELY AFTER MEMBRANE APPLICATION
- 6) SEALANT IS A MAINTENANCE ITEM AND IS NOT COVERED UNDER THE ROOFPRO WARRANTY
- 7) NON STRUCTURAL CRACKS MUST BE REPAIRED PRIOR TO SIKALASTIC APPLICATION

BUILDING TRUST
CONSTRUIRE LA CONFIANCE
 800-933-7452



DETAIL NAME:

IRREGULAR PENETRATION FLASHING

SCALE:

N.T.S.

DATE:

06/22

DETAIL NO.:

LAM CAN 7-3