

## NOTES:

- 1) NEW OR EXISTING WOOD NAILERS SHALL BE ATTACHED ACCORDING TO THE DESIGNER OF RECORD., THE NATIONAL BUILDING CODE OF CANADA, LOCAL CODE, OR INSURANCE REQUIREMENTS, WHICHEVER IS MORE STRINGENT.
- 2) BRING BAREBACK MEMBRANE OVER ROOF EDGE AND DOWN OUTSIDE FACE OF WALL, COVERING WOOD NAILER(S) COMPLETELY. BRING FELTBACK MEMBRANE TO ROOF EDGE ONLY.
- 3) FACE DIMENSION OF FASCIA SHALL BE A MINIMUM OF 3" OR AS OTHERWISE REQUIRED TO EXTEND A MINIMUM OF 1-1/2" BELOW BOTTOM OF WOOD NAILER.
- 4) THE HORIZONTAL FLANGE OF FASCIA SHALL BE A MINIMUM OF 4" WIDE.
- 5) SCREWS USED TO ATTACH EITHER THE CONTINUOUS CLEAT OR FASCIA SHALL PENETRATE THE NAILER A MINIMUM OF 1".
- 6) FASTENER WITHDRAWAL RESISTANCE SHOULD BE 100 LB MIN. USE NO. 8 MIN. SCREWS PENETRATING 3/4". FASTENER IS PLACED EITHER CENTERED INTO TOP WOOD NAILER OR 1" FROM TOP EDGE OF CLEAT HOOK STRIP @ 4" O.C.
- 7) FASTENED 4" O.C. AND STAGGERED BETWEEN 1" AND 1-1/2" FROM TOP BACKSIDE EDGE OF FASCIA COVER. THE MAXIMUM RATING ACHIEVED FOR (L) DIMENSION FASCIA HEIGHT IS AS FOLLOWS: 210 PSF @ 8", 310 PSF @ 6", AND 470 PSF @ 4"
- 8) SEE DETAIL CAN 1-1B FOR SARNACLAD METAL JOINTS



## DETAIL NAME: SARNACLAD METAL EDGE (FELTBACK MEMBRANE)

**BUILDING TRUST** 800-933-7452

SCALE: N.T.S. CAN 1-1-FB