

BUILDING TRUST CONSTRUIRE LA CONFIANCE

# PRODUCT DATA SHEET EVOLUTION Pro 1

A polymeric sand to be used in joints between concrete pavers no wider than 25mm (1 in)

## **PRODUCT DESCRIPTION**

EVOLUTION Pro 1 polymeric sand is a professional quality product made from specially screened sand and the latest binders high concentration technology. EVOLUTION Pro 1 is ideal for filling joints between pavers/stones when constructing pavements, driveways, patios or parking lots in commercial or residential applications. Your pavers will be firmly stabilized and will remain flexible to movement, in the most extreme weather conditions.

## WHERE TO USE

- Application range in joint thickness from 3 to 25 mm (1/8 to 1 in).
- For concrete pavers
- Can be used horizontally or on a slope

## **CHARACTERISTICS / ADVANTAGES**

- No haze
- Low dust
- One step watering installation
- Helps prevent the growth of ant nests and weeds
- Increased flexibility to better resist freeze-thaw cycles

Packaging	22.7 kg (50 lb) bag
Shelf Life	12 months in original, unopened bag.
Storage Conditions	Store dry, ensuring that product is not exposed to rain, condensation or high humidity.
Colour	Available in two (2) natural colours: • Beige • Carbon Gray
Maximum Grain Size	ASTM C 144 et CSA 179
Compressive Strength	5.4 MPa (783 psi) at 28 days
Yield	A 22.7 kg (50 lb) bag of EVOLUTION Pro 1 polymeric sand can cover approximately between 1.7 and 11.8 m <sup>2</sup> (18 and 27 ft <sup>2</sup> ) of pavers depending on the shape width of the joints and thickness of the pavers used.
Substrate Moisture Content	The application substrate (the pavers) must be completely dry before application.
Final Set Time	220 minutes

## **PRODUCT INFORMATION**

Product Data Sheet EVOLUTION Pro 1 August 2024, Version 01.01 020201010030000270 Allow the surface to dry for 24 hours before opening to foot traffic, and 72 hours before opening to vehicular traffic. Longer drying times may be required when temperatures are below 21 °C (70 °F) for the first 24-72 hours after installation of EVOLUTION Pro 1. Protect joints from rain for a minimum of 24 hours. Ensure that any sprinkler systems that are in close proximity to the newly applied EVOLUTION Pro 1 remain off for a minimum of 72 hours after installation.

## **BASIS OF PRODUCT DATA**

Product properties are typically averages, obtained under laboratory conditions. Reasonable variations can be expected on-site due to local factors, including environment, preparation, application, curing and test methods.

## WHERE TO USE

- Not to be used with clay pavers
- The entire paver joint must be filled with EVOLUTION Pro 1, do not partially fill joints with any another material.
- Do not overwater EVOLUTION Pro 1 during application and stop showering once the material can no longer accept water.
- Do not displace the EVOLUTION Pro 1 with water during showering.
- Do not use a water hose with a nozzle that generates a high pressure jet
- Do not use in areas that are submerged or constantly wet. Joints can soften when saturated with water but will harden again after drying.
- Do not use in conjunction with pavers installed directly over a concrete slab. A drainage base is required between the concrete slab and pavers to ensure that the joints do not remain saturated. See ICPI Tech Spec #2 for further information.

## **ENVIRONMENT, HEALTH & SAFETY**

#### NOTES ON INSTALLATION

- It is important to execute the work in good weather conditions. No rain should be expected within 24 hours following installation. A thunderstorm or heavy rainfall can wash away the polymer sand and displace it on the paved surface. Cover the surface in case of any inclement weather!
- Make sure the pavers, slabs or stones are dry before you start spreading the sand to avoid sticking or staining. Furthermore, make sure that pavers are free of polymeric sand before spraying with water.
- NOTE: The combination of a very steep slope and wide joints can reduce the ability for water penetration into the joints, due to surface water slippage. In this case, we recommend installing the product in a small test area before proceeding.
- Before using sealers or cleaners, it is recommended to wait at least 30 days. Check with the paver

manufacturer to determine if it is safe to use these products on your paver surface.

Before attempting touch up's and or re installations of polymeric sand, the existing sand must be removed to the full depth of the paver and or a minimum of 38.1 mm (1.5 in) before re sanding.

#### EQUIPMENT

Tools for the installation on hand: Stiff bristled push broom, soft bristle push broom, leaf blower, vibrating plate, spray nozzle with shower setting.

#### APPLICATION

**STEP 1** - SPREADING: Pour and spread the EVOLUTION Pro 1 polymeric sand on the paved surface. Important: surface must be completely dry.

**STEP 2** - JOINT FILLING: Using a push broom, spread the polymeric sand over the joints making sure to fill to the full depth of the paver, stone or slab, leaving a 3 mm (1/8 in) reveal. NOTE: The manufacturers of some types of pavers recommend the removal of any polymeric sand from the surface of the pavers using a push broom and a leaf blower before proceeding to step 3. Some also recommend to use a vibrating plate machine equipped with a Teflon plate at step 3. Please verify the recommendations of your paver manufacturer before installation.

**STEP 3** - COMPACTING: Use a vibrating plate over the entire paver surface for joints less than 6 mm (1/4 in). Repeat steps 1 to 3 if necessary to make sure the joints have been filled to at least 3 mm (1/8 in) below the paver surface.

**STEP 4** - SWEEPING & CLEANING: To ensure that no sand sticks to the surface of the pavers, use a stiff bristled broom for the initial sweeping of the EVOLUTION Pro 1 polymeric sand. Then use a soft bristle broom to sweep the excess sand off the surface. Finally, use a leaf blower to ensure the removal of any excess sand residue from the surface. These two cleaning steps are important before proceeding to step 5.

**STEP 5** - WATERING / ACTIVATION: Water 5 m<sup>2</sup> (50 ft<sup>2</sup>) sections at a time, ensuring your spray nozzle is set to the "**shower**" position. Always begin the one step watering process from the lowest part of the project. Using the shower head position, generously shower the pavers one time, approximately up to 1 minute per 5 m<sup>2</sup> (50 ft<sup>2</sup>) in a left and right motion, while ensuring no displacement of polymeric sand from the joints. It is recommended to check if the water has filtered down to at least 25 mm (1 in) of the depth of the joints. To do

 Product Data Sheet

 EVOLUTION Pro 1

 August 2024, Version 01.01

 020201010030000270



**BUILDING TRUST CONSTRUIRE LA CONFIANCE**  this, simply use a screwdriver and lift up the sand, then pack-it back in to it's original position.

**STEP 6** - DRYING/SETTING: Remove any standing water from the surface of the paver with a leaf blower. For optimum performance, a minimum of 24 hours is required to allow the polymer sand to cure and harden properly. Do not walk or drive on the paved surface during this period. The curing and hardening process will take much longer in cold, damp weather. The longer the curing time, in dry and warm conditions, the better and more durable the final result will be. Use this product at temperatures over 0 °C (32 °F). In case of unexpected rainfall during the drying period, we recommend temporarily covering the area with a tarp and removing it after rain stops.

#### **CLEAN UP**

Clean any tools or equipment after use with water.

## **LEGAL NOTES**

The information, and in particular, the recommendations relating to the application and enduse of Sika products, are given in good faith based on Sika's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika's recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any recommendations, or from any other advice offered. The information contained herein does not relieve the user of the products from testing them for the intended application and purpose. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request or may be downloaded from our website at: www.sika.ca

#### Sika Canada Inc.

Head Office 601, avenue Delmar Pointe-Claire, Quebec H9R 4A9 1-800-933-SIKA www.sika.ca Other locations

Boisbriand (Quebec)

Edmonton (Alberta)

Brantford; Cambridge;

Sudbury: Toronto (Ontario)

Surrey (British Columbia)

#### Product Data Sheet EVOLUTION Pro 1

August 2024, Version 01.01 020201010030000270 EVOLUTIONPro1-en-CA-(08-2024)-1-1.pdf



### BUILDING TRUST CONSTRUIRE LA CONFIANCE