

NOTE: DO NOT INSTALL RHINOBOND PLATES TIGHT AGAINST WALL. THE RHINOBOND WELDER IS 7" WIDE AND MUST BE CENTERED OVER THE RHINOBOND PLATE FOR PROPER WELDING

