



NOTE:

- 1) MINIMUM PERIMETER DETERMINED BY THE NATIONAL BUILDING CODE OF CANADA CALCULATIONS.
- 2) A MINIMUM OF 2 PERIMETER HALF SHEETS MUST BE USED.
- 3) INTERMEDIATE FASTENER ROWS TO BE INSTALLED MIDWAY BETWEEN THE FASTENER ROWS.



INSEAM SARNAFIL\SIKAPLAN CORNER LAYOUT FOR 10 FT. SHEET

BUILDING TRUST 800-933-7452

can.sika.com

N.T.S.

SCALE:

04/22

CAN SLC 01