



NOTES:

- 1) METAL FOIL TAPE MUST COVER THE ENTIRE LENGTH OF SIKALASTIC MEMBRANE AT TIE-IN
- 2) METAL FOIL TAPE MUST BE PLACED ALONG THE LEADING EDGE OF THE NON COMPATIBLE MATERIAL AND UP ALL LAP EDGES OF THE NON COMPATIBLE MATERIAL TO MITIGATE BLEEDING OF NON-COMPATIBLE MATERIALS ONTO SIKALASTIC MEMBRANE
- 3) NON STRUCTURAL GAPS MUST BE FILLED PRIOR TO SIKALASTIC APPLICATION.
- 4) REFER TO LAM CAN 1-0 FOR AN ANGLE TRANSITIONAL WITH CRACKS.
- 2) SEALANT IS A MAINTENANCE ITEM AND IS NOT COVERED UNDER THE ROOFPRO WARRANTY.

BUILDING TRUST
CONSTRUIRE LA CONFIANCE
 800-933-7452



DETAIL NAME:

ALTERNATE EQUIPMENT PAD

SCALE:

N.T.S.

DATE:

06/22

DETAIL NO.:

LAM CAN 5-4B